

This device allows to control up to 12 independent automations from a single workstation. Set all configuration parameters from **ETERE Control Panel**.



## **OPERATION**

To select the automation to be controlled, just press one of the 12 black buttons on the left (see picture below). The cap of each button can be removed to insert a description to identify the relevant automation.



Once the automation has been selected, you can send it different commands using the colored buttons on the right (see picture below). In this case also you can insert a description of the connected function.



The lighting of colored buttons is remotely controlled by the control software: when a button is lighted ETERE Control Panel has got the command.

## **TECHNICAL CHARACTERISTICS**

Interface	Standard Rs422
Control connector	Db9
Optical information	Light buttons
Temperature field	from $+ 5$ to $+ 45^{\circ}$ C
Moisture	< 90 %
Power supply	220 V 47-63 Hz
Power consumption	< 50 VA
Dimensions	rack standard 19" 1 U
(Mm)	44 (H)x 483 (W)x 280 (D)
Weight	1 Kg

## USE

Once the device has been configured, use the operative buttons to send the associated command (play, rec., stop, rew, ff., etc.) to the automation in use.

If the command has been properly received, light will show on the pressed **button**.

-

Back panel



tere Lere

ETERE P.O.Box 129 62029 Tolentino Italy info@etere.com www.etere.com Tel. +39 0733 9564 Fax +39 0733 956335